

10. The effective voltage for an a.c. sinusoidal source is found by taking 0.707 times the maximum of the sinusoidal signal. Here that gives us

$$V_{\text{eff}} = (180 \text{ V}) (0.707) = 127.3 \text{ V}$$